

## ENTRANCE HANDLESET Drilling Template

EH707



## **CAUTION**

Although a door can be prepared by an untrained person, we recommend that measurements and drilling be done by a skilled carpenter or locksmith.

- 1 Decide on height of door (recommended centreline is 914mm from floor).
- 2 Decide on backset (ie, distance from door edge to centre of handle).
- Fold template using required backset.
- Position on required height of door.
- Mark the correct hole positions for this handleset.
  Note: the two 25mm hole positions must be central to the door face.
- 6 Double check measurements against handleset before drilling into door face.
- 7 Drill 1x 54mm hole for deadbolt, 1 x 54mm hole for handleset, and 1x 9mm hole.
- 8 Drill 2x 25mm holes in centre of door face to the depth of latch and deadbolt.

G.D. Rutter Limited 127 Diana Drive, Glenfield, Auckland PO Box 100-183 NSMC, Auckland 0745 Phone: 09 444 5359 Facsimile: 09 444 3972

