

### **INFLATION**

Inflate through the valve using breaths or hand/electric pump. Use pump as per manufacturer's instructions.

### **DEFLATION**

Remove the top cap and press in rubber seal on the inside of the valve. This will release the air. Roll the bed carefully from the opposite end towards the valve to complete deflation.

### **IMPORTANT**

1. Do not over inflate as this may cause damage to the mat and void warranty.
2. Do not leave your mat in direct sunlight as this will weaken the fabric and cause the air pressure to increase.
3. Do not inflate mat on rough ground, this may cause punctures.
4. Do not place excessive stress on the seams by jumping or bouncing.
5. This is not a floatation device.
6. Ensure the mat is completely dry before storage.
7. Wipe/sponge clean with mild detergent only.

### **TO REPAIR**

1. Deflate the mat.
2. Clean and dry the damaged area to remove all traces of oil and grease.
3. Apply the glue, then patch immediately. Apply pressure for 2 minutes.
4. Apply glue to the edge of the patch for sealing purposes.
5. Allow at least 30 minutes drying time before re-inflating the mat.