


## LEVER KEYHOLE




1. Install lock into the door as per instructions
2. Measure backset of lock by measuring the distance from the door face to the lock spindle hole.
3. Using the drilling template supplied, mark out, and drill holes for your handle.
4. Decide on door handing
5. Fit blank head screws to the outside door handle and install hex posts by tightening with a spanner.
6. Insert the spindle into the outside door handle with split aligned vertically.
7. Slide outside door handle onto door.
8. Align inside handle and install onto door fastening with Phillips head screws provided (cutting with hacksaw may be required due to door thickness).
9. Secure handles to installed spindle with grub screws.

Bend template on this line →

Note: Drill 1x set of holes, either for:

- A** 45mm backset = ○
- B** 58mm backset = ○



Note: If reprinting this template, ensure you print 1:1 ratio, and double check the drilling template with an accurate ruler.

